
Clearing Paper Jams


Remove any jammed paper in Cassette 1 and 2

Here, we'll explain the procedures for cassette 1, as an example.





- · Do not reuse jammed papers.
- If the paper tears during removal, be sure to remove any loose scraps of paper from inside the machine. Scraps of paper left in the machine could cause subsequent jamming.

Pull Cassette 1 out toward you until it stops.



7 Remove any jammed paper.





Push Cassette 1 back in.

