

# Remove any jammed paper in the Multipurpose Tray


## CAUTION

- Do not reuse jammed papers.
- If the paper tears during removal, be sure to remove any loose scraps of paper from inside the machine. Scraps of paper left in the machine could cause subsequent jamming.

### 1 Remove any jammed paper.



### 2 Remove all the paper.



### 3 Reload the paper.

