Regular Maintenance

Cleaning Slit Glass

Clean the slit glass surface and the reading guide with the supplied cleaning cloth.




Clean the slit glass surface with the supplied cleaning cloth.

NOTE

Dirt on the slit glass or the reading guide may cause black streaks to appear in the output.

Remove the cloth from the cleaning cloth compartment.



Clean the slit glass surface and the reading guide.

