
## **Clearing Paper Jams**

Remove any jammed paper in the 4,000-sheet Finisher/100-sheet Staple Finisher (Tray A)

## **A**CAUTION


- · Do not reuse jammed papers.
- If the paper tears during removal, be sure to remove any loose scraps of paper from inside the machine. Scraps of paper left in the machine could cause subsequent jamming.
- Remove any jammed paper.




Open the finisher front cover 1.




3 Open the conveyor guide (D6).




Remove any jammed paper.




5 Return the conveyor guide (D6) to the original position.




6 Open the conveyor guide (D4).




7 Turn knob (D5).




Remove any jammed paper.




9 Return the conveyor guide (D4) to the original position.




10 Open the conveyor guide (D1).



## 1 1 Remove any jammed paper.



12 Return the conveyor guide (D1) to the original position.



13 Return the cover to the original position.

